

---

## Pre-Set Program List

### **▲ P1, Comfort mode on:**

- ▲ Weekdays: From 07:00 to 09:00 h and from 17:00 to 23:00 h
- ▲ Weekends: From 08:00 to 23:00 h

### **▲ P2, Comfort mode on:**

- ▲ Weekdays: From 07:00 to 09:00 h from 12:00 to 14:00 h and from 18:00 to 23:00 h
- ▲ Weekends: From 08:00 to 23:00 h

### **▲ P3, Comfort mode on:**

- ▲ Weekdays: From 06:00 to 23:00 h
- ▲ Saturdays: From 07:00 to 24:00 h
- ▲ Sundays: From 00:00 to 01:00 h and from 07:00 to 23:00 h

### **▲ P4, Comfort mode on:**

- ▲ Weekdays: From 15:00 to 23:00 h
- ▲ Saturdays: From 07:00 to 24:00 h
- ▲ Sundays: From 00:00 to 01:00 h and from 07:00 to 23:00 h

### **▲ P5, Comfort mode on:**

- ▲ Weekdays: From 06:00 to 08:00 h and from 21:00 to 23:00 h
- ▲ Saturdays: From 07:00 to 09:00 h and from 18:00 to 24:00 h
- ▲ Sundays: From 07:00 to 09:00 h and from 18:00 to 23:00 h

### **▲ P6, Comfort mode on:**

- ▲ Weekdays: From 06:00 to 08:00 h and from 14:00 to 21:00 h.
- ▲ Weekends: From 07:00 to 21:00 h.

### **▲ P7, Comfort mode on:**

- ▲ Weekdays: From 07:00 to 19:00 h
- ▲ Weekends: Inactive (ECO Mode)

### **▲ P8, Comfort mode on:**

- ▲ Weekdays: From 08:00 to 19:00 h
- ▲ Saturdays: From 08:00 to 18:00 h
- ▲ Sundays: Inactive (ECO Mode)

### **▲ P9, Comfort mode on:**

- ▲ Monday: From 00:00 to 07:00 h
- ▲ Tuesday-Thursday: Inactive (ECO Mode)
- ▲ Friday: From 13:00 to 24:00 h
- ▲ Weekends: From 00:00 to 24:00 h